



Assembly Instructions

ANCHORING A TENT

Staking Into Grass:

Both Pole and Frame tents can be staked into the ground. The number of stakes depends on the tent's style and size. The stakes we use to secure the tents are about one inch in diameter and go roughly two feet into the ground.

Staking Into Asphalt:

Both Pole and Frame Tents can be staked into asphalt. We use the same size stakes for grass and asphalt installation.

After removing the stakes from the asphalt, our crew will put an asphalt plug (color of the asphalt plug is black) into each hole so it is flush with the asphalt. This is a great option for rentals that are done annually or more often, and can continue to use the same holes, as long as the same size tent is used again.

It is always best to call 811 to ensure your lines are marked off in case some lines run under the asphalt.

Concrete Blocks:

Concrete blocks are able to be used when staking is not an option.

We use 350 lb concrete blocks to secure our tents. The amount of blocks needed is determined by the size of the tent and weather conditions leading up to your rental reservation.